



HALF CUT, BEND OVER AND SHAPE TO CYLINDER. JOIN AT MIDDLE TO MAKE MOTOR MOUNT

GUIDE ONLY, CUT AT ANGLE TO SUIT FINS

POSITION OF MOTOR MOUNT, SHAPE ON FIT

RUDDER OPTION  
SHAPE RUDDER TO HERE BOTH SIDES.