



<< MOVE AILERONS OUTWARDS TO ENDS AFTER GLUING END TAPERS >>

<< MOVE AILERONS OUTWARDS TO ENDS AFTER GLUING END TAPERS >>

USE TO REINFORCE WING STRUTS AT WING JOINT

LAMINATE 2 VERTICAL FUSES TOGETHER